

hpssacli raid array commands

Logical Drives

```
hpssacli controller slot=0 ld all show status /* show status */
hpssacli controller slot=0 ld 5 modify reenable /* reenable logical drive */
hpssacli controller slot=0 ld 5 delete /* delete logical drive */
hpssacli ctrl slot=0 create type=ld drives=1I:1:8 raid=0 stripsize=1024 /*
create RAID-0 ld using single disk */
hpssacli controller slot=0 ld 4 modify raid=1 /* change raid level on
logical drive */
```

Physical Disks

```
hpssacli controller slot=0 pd all show status /*show status*/
```

From:

<https://wiki.dewberry.co.za/> - Shaun's Wiki

Permanent link:

https://wiki.dewberry.co.za/doku.php?id=hp_storage_controller

Last update: 2019/09/16 16:09

