

| Command | Action |
|---|--|
| <code>./MegaCli64 -FwTermLog -Dsply -aALL > /tmp/ttylog.txt/</code> | Creates the RAID controller log (ttylog) |
| <code>./MegaCli64 -PDList -aALL > /tmp/disks.txt</code> | Creates a list with information about the RAID controllers, virtual disks and hard disks installed |
| <code>./MegaCli64 -LDInfo -LALL -aALL > /tmp/LDinfo.txt</code> | Creates a list with information about existing RAID volumes and configurations |
| <code>./MegaCli64 -AdpAllInfo -aALL > /tmp/Adapterinfo.txt</code> | Creates a list with information about RAID controller settings |
| <code>./MegaCli64 -AdpBbuCmd -aALL > /tmp/Battery.txt</code> | Creates a detailed list of the battery status of the RAID controller (state of charge, learning cycle, etc.) |
| <code>./MegaCli64 -AdpEventLog - IncludeDeleted -f deleted.txt -aALL</code> | Creates the RAID controller log (ttylog) with all information since very first controller initialization (Note: This file will always be saved in the MegaCLI root folder) |

From:

<https://wiki.dewberry.co.za/> - **Shaun's Wiki**

Permanent link:

https://wiki.dewberry.co.za/doku.php?id=lsi_logic_symbios_megaraid&rev=1575978380Last update: **2019/12/10 11:46**