Command	Action
`./MegaCli64 -FwTermLog -Dsply -aALL > /tmp/ttylog.txt/`	Creates the RAID controller log (ttylog)
`./MegaCli64 -PDList -aALL > /tmp/disks.txt`	Creates a list with information about the RAID controllers, virtual disks and hard disks installed
`./MegaCli64 -LDInfo -LALL -aALL > /tmp/LDinfo.txt`	Creates a list with information about existing RAID volumes and configurations
`./MegaCli64 -AdpAllInfo -aALL > /tmp/Adapterinfo.txt`	Creates a list with information about RAID controller settings
`./MegaCli64 -AdpBbuCmd -aALL > /tmp/Battery.txt`	Creates a detailed list of the battery status of the RAID controller (state of charge, learning cycle, etc.)
`./MegaCli64 -AdpEventLog -IncludeDeleted -f deleted.txt -aALL`	Creates the RAID controller log (ttylog) with all information since very first controller initialization (Note: This file will always be saved in the MegaCLI root folder)